

Margherita Cavallo¹, Ryosuke Nakazato², Natale Gabriele Porcaro¹, Melodj Dosa¹, Matteo Signorile¹, Silvia Bordiga¹, Nataly Carolina Rosero-Navaro², Kiyoharu Tadanaga², Valentina Crocellà¹, Francesca Bonino¹



¹ Department of Chemistry, NIS and INSTM Reference Centers, Università di Torino, Via Quarello 15/A, 10135 Torino, Italy10135, Italy
² Division of Applied Chemistry, Faculty of Engineering, Hokkaido University, Sapporo 060-8628, Hokkaido, Japan

e-mail: margherita.cavallo@unito.it

The electrochemical CO₂ reduction reaction (CO₂RR) is considered a promising strategy for CO₂ conversion and ultimately for lowering greenhouse gases emissions.¹ Recently, layered double hydroxides (LDHs) attracted increasing attention as an alternative to precious metal catalysts thanks to its strong affinity with CO₂ in water, stability in basic electrolytes, affordability of its components and high ion conductivity.²


Materials and methods

Three LDH with different chemical composition Ni-Al and Ni-Fe and Zn-Al LDH (2:1) were synthesized, characterized (using XRD, TGA, EDX and volumetry) and evaluated as potential electrocatalysts for CO₂ reduction into CO.³




Zn-Al LDH shows a 67% selectivity for CO and 92% selectivity for CO and H₂ at -1.4V vs. RHE with KHCO₃ as an electrolyte

A preliminary *in-situ* ATR-IR spectroscopical characterization was performed miming the electrocatalytic conditions studying the CO₂ adsorption in absence of potential to explain the different performances into CO evolution reaction.




Results and...

The interaction of CO₂ with LDHs show different carbonates evolution.⁴




The differences in the spectra of Ni-Al, Ni-Fe and Zn-Al suggest the formation of different families of bidentate carbonates with different strength and stability, which might suggest a different catalytic behavior in the tree LDHs.




...next steps


Given the highest CO evolution of Zn-Al LDH 2:1, the same sample with other two different stoichiometry were synthesized and tested: Zn-Al LDH 1:2, Zn-Al LDH 1:1



In-situ ATR-IR spectroscopy



The *in-situ* ATR-IR spectroscopic characterization was performed in both H₂O and C₆H₁₂. Thanks to this characterization it was possible to perform a deconvolution of the carbonate species



Conclusion

- The Zn-Al LDH 1:2 which is showing the best electrocatalytic performances is characterized by an higher evolution in monodentate carbonates.
- Ni-Al, Ni-Fe and Zn-Al LDH (2:1) show differences only in the evolution of bidentate carbonates species.
- The formation of monodentate carbonate is probably associated to an higher electrocatalyst reactivity.

In future a real *operando* spectroscopic characterization will be performed (i.e. in presence of potential).

ACKNOWLEDGMENTS & REFERENCES

This project has received funding from the European Union's Horizon 2020 research and innovation programme under Grant Agreement No 101022633. This project is supported by Japan Science and Technology Agency (JST) (Grant Agreement No JPMJSC2102) and São Paulo Research Foundation (FAPESP) (Grant number 2022/04751-0).



- [1] X. Duan, J. Xu, Z. Wei, J. Ma, S. Guo, S. Wang, H. Liu, S. Dou, Adv. Mater., 29 (2017) 1701784.
- [2] Y. Furukawa, K. Tadanaga, A. Hayashi, M. Tatsumisago, Solid State Ionics., 192 (2011) 185–187.
- [3] R. Nakazato et al. RSC Sustain. (submitted)- SU-ART-04-2023-000124
- [4] Stevens, R. W., Siriwardane, R. V. & Logan, J., Energy & Fuels, 22 (2008) 3070–3079.